


TOKU LINK BENDER (TKRB-16)
EXPLODED DRAWING



REF.No	DESCRIPTION
1	GEAR BOX
2	PUMP GEAR
3	PUMP SPRING
4	PUMP BODY
5	GEAR
6	PUMP DRIVE GEAR
7	SWING BRACKET
8	ROLLER
9	BOLT
10	BRACKET & STUD
11	TOP PLATE
12	SWING SUPPORT
13	MAIN SHAFT
14	SCALE
15	BODY
16	SPRING
17	PADDLE CONNECTOR
18	SPRING HOLDER
19	CLUTCH PADDLE
20	CLUTCH CONNECTOR
21	BEARING
22	CLUTCH HOUSING
23	BEARING
24	BEARING
25	UPPER CLUTCH
26	BEARING
27	MIDDLE CLUTCH
28	LOWER CLUTCH
29	SPRING
30	BEARING
31	BEARING
32	GEAR
33	BEARING
34	BUSH
35	BEARING
36	BEARING HOUSING
37	BEARING
38	LOCK NUT
39	SHAFT COVER
40	BOTTOM SPRING